

Sigma Release No.	Build No.	Software/Firmware	File Date	SigmaX
Release 1	1.52	Software/Firmware	22.06.2001	SigmaX 4.5
Release 2	2.13	Software/Firmware	14.02.2002	SigmaX 5.2
Release 2	3.12	Supplement	14.02.2002	SigmaX 5.2
Release 3	3.12	Software	31.07.2002	SigmaX 5.2
Release 3.1	3.17	Software	17.09.2002	SigmaX 5.2
Release 3.3	3.3	Software	30.07.2003	SigmaX 5.2
Release 3.4	3.31.1	Software	03.10.2003	SigmaX 5.2
Release 3.6	3.32.10	Software	19.11.2003	SigmaX 5.2
Release 3.7	3.33.9	Software	22.12.2003	SigmaX 5.2
Release 3.7 SP2	3.33.11	Software	27.01.2004	SigmaX 5.2
Release 3.7 SP3	3.33.13	Software	19.02.2004	SigmaX 5.2
Release 3.10	3.34.11	Software	21.04.2004	SigmaX 5.2
Release 3.11	3.34.11	Supplement	31.08.2004	SigmaX 5.2
Release 4.00	3.36.11	Software	16.12.2005	SigmaX 6.0.1
Release 4.00 SP2	3.36.16	Software	02.03.2006	SigmaX 6.0.1
Release 4.00 SP4	3.36.20	Software	23.05.2006	SigmaX 6.0.1
Release 4.01	3.37.08	Software	07.09.2006	SigmaX 6.0.1
Release 4.01 SP1	3.37.09	Software	26.09.2006	SigmaX 6.0.1
Release 4.01 SP3	3.37.12	Software	20.10.2006	SigmaX 6.0.1
Release 4.01 SP4	3.37.13	Software	13.08.2006	SigmaX 6.0.1
Release 4.01 SP4a	3.37.16	Software	17.11.2006	SigmaX 6.0.1
Release 4.01 SP5	3.37.18	Software	05.01.2007	SigmaX 6.0.1
Release 4.02	3.39.09	Software	26.01.2007	SigmaX 6.0.1
Release 4.03	3.40.06	Software	06.06.2007	SigmaX 6.0.1
Release 4.03 Sp1	3.40.09	Software	09.08.2007	SigmaX 6.0.1
Release 4.04	3.41.14	Software	27.02.2008	SigmaX 6.0.1
Release 4.04 SP1	3.41.15	Software	09.05.2008	SigmaX 6.0.1
Release 4.04 SP2	3.41.16	Software	15.09.2008	SigmaX 6.0.1
Release 4.04 SP3	3.41.18	Software	08.01.2009	SigmaX 6.0.1
Release 4.04 SP4	3.41.19	Software	08.01.2009	SigmaX 6.0.1
Release 4.05	3.42.34	Software	06.11.2009	SigmaX 6.0.1
Release 4.05 SP1	3.42.43	Software	22.03.2010	SigmaX 6.0.2
Release 4.05 SP2	3.42.48	Software	26.08.2010	SigmaX 6.0.2
Release 4.05 SEB	3.43.18	Software	08.12.2010	SigmaX 6.0.2
Release 4.06	3.44.14	Software	01.12.2011	SigmaX 6.0.2
Release 4.06 SP1	3.44.16	Software	01.12.2011	SigmaX 6.0.2
Release 4.06 SP1	3.44.18	Hotfix	01.02.2012	SigmaX 6.0.2
Release 4.07	3.45.48	Software	20.08.2012	SigmaX 7.0.6
Release 4.07 SP1	3.45.51	Service Pack	09.12.2012	SigmaX 7.0.6
Release 4.07 SP2	3.45.58	Service Pack	20.12.2013	SigmaX 7.0.6
Release 4.08	3.46.57	Software	10.04.2014	SigmaX 7.0.7
Release 4.08	3.46.62	Hotfix	21.05.2014	SigmaX 7.0.7
Release 4.08	3.46.70	Hotfix	23.07.2014	SigmaX 7.0.7
Release 4.08	3.46.72	Hotfix	04.08.2014	SigmaX 7.0.7
Release 4.08	3.46.73	Hotfix	12.08.2014	SigmaX 7.0.7
Release 4.08	3.46.79	Hotfix	08.10.2014	SigmaX 7.0.7
Release 4.08 (**1)	3.46.80	Software	10.04.2014	SigmaX 7.0.7
Release 4.08	3.46.81	Hotfix	17.02.2015	SigmaX 7.0.7
Release 4.08	3.46.85	Hotfix	19.03.2015	SigmaX 7.0.7
Release 4.08	3.46.86	Hotfix	19.03.2015	SigmaX 7.0.7
Release 4.08 (**2)	3.46.89	Software	10.04.2014	SigmaX 7.0.7
Release 4.08	3.46.98	Hotfix	14.12.2016	SigmaX 7.0.7
Release 4.08 (**3)	3.46.104	Software	28.02.2017	SigmaX 7.0.9
Release 4.08 (**4)	3.46.105	Hotfix	10.03.2017	SigmaX 7.0.9
Release 4.08 (**5)	3.46.106	Software	28.03.2017	SigmaX 7.0.9
Release 4.08	3.46.107	Hotfix	08.08.2017	SigmaX 7.0.9
Release 4.08	3.46.108	Hotfix	01.05.2018	SigmaX 7.0.9
Release 4.08 (**6)	3.46.110	Software	13.05.2019	SigmaX 7.0.9
Release 4.08 (**7)	3.46.111	Software	27.11.2019	SigmaX 7.0.9

- Notes:
- \*\*1 Sigma 3.46.57 with StruxureWare Building Operation v1.5 or 1.6 transition support Program installed.
  - \*\*2 Sigma 3.46.57 with StruxureWare Building Operation v1.8 transition support Program installed.
  - \*\*3 Sigma 3.46.57 with StruxureWare Building Operation v1.9 transition support Program installed.
  - \*\*4 Sigma 3.46.57 with StruxureWare Building Operation v1.9 Hotfix to Support Program installed.
  - \*\*5 Sigma 3.46.57 with EcoStruxure Building Operation v2.0.1 transition support Program installed.
  - \*\*6 Sigma 3.46.57 with EcoStruxure Building Operation v3.0.1 transition support Program installed.
  - \*\*7 Sigma 3.46.57 with EcoStruxure Building Operation v3.1.2 transition support Program installed.